

Gator Kit Installation Instructions

PKT-059



Introduction:

Made in USA

This high quality, Powerlet™ MultiFit kit provides an easy way to connect a Powerlet socket (BMW type) to almost any motorcycle. The kit is simple to install. The operator can supply power to the battery (i.e. battery charger), draw power from the battery, or monitor the state of charge on the battery.

Connect the terminals as follows:

RED WIRE = BATTERY POSITIVE

BLK WIRE = BATTERY NEGATIVE

The center terminal is plus and the outer ring is negative (see dwg below).
Install the fuse in the fuse-holder.

Required Tools:

- None.

Parts List:

- Wiring harness with ATO Waterproof Fuse-holder
- 15A ATO fuse
- Insulated Gator Terminal Clamps



POWERLET CONNECTOR

