

## 3-Position Controller Instructions



### Features:

- A Single button controls the three heat levels-low/medium/full on and full off
- Solid State, High Tech, Safe & Reliable Electronics designed by us
- Fits comfortably into the palm of the hand or pocket
- LED for Heat Level Feedback
- Battery harness made of automotive grade wire that is resistant to oil, acid, water & grime with auto style fuse
- Plug compatible with most DC heated products
- Handles 10 amps at 13 volts with internal reset for overloads & shorts
- Optional Remote Controller with Silicon Cover & Wrist Strap easily mates to 3-Position Controller

### Instructions for Installing Battery Harness:

1. Turn Off the Vehicle, Generator or Any Charging source for the Battery
2. At the Battery, Disconnect the Ground (-) Cable from the Battery First
3. Then Disconnect the Plus (+) Cable from the Battery
4. Attach the positive ring terminal from the battery harness to the positive terminal on the battery. The positive ring terminal can be distinguished from the negative by the fact that it has a fuse attached to the Wire. Reattach the bolt to the battery and tighten.
5. Attach the negative ring terminal from the battery harness to the negative terminal on the battery. The negative ring terminal can be distinguished from the positive by the fact that it does NOT have a fuse attached to the Wire. Reattach the bolt to the battery and tighten.
6. Secure the wire harness with cable straps. Be certain the wire harness and all cords are not pinched. The connecting plug should be easily accessible but clear of all moving parts.

### Installing Your 3-Position Controller:

1. Attach the plug of the 3-Position Controller marked "power in" to the connecting plug on the battery harness.
2. Attach the plug marked "power out" directly to the garment.
3. Remember - the plug marked "power in" always goes to the power source; the one marked "power out" always goes to the garment. If the 3-Position Controller is not plugged in correctly, it will not work.

### Using the 3-Position Controller:

1. Use the Button on the Receiver to Control the Heat Level
2. The 3-Position Controller has 3 Heat Level Settings and Off. Pressing the Button Changes the heat Levels from Hi (Red LED) to Medium (Yellow LED) to Low (Green LED) to Off.
3. You Must Wait 2 seconds between pressing the button to change the setting.
4. When you First Press the Button the LED will Show you the Level you are on. The Next Press Will Change it.

### CAUTION:

It is possible to overload your charging system by adding too many electrical accessories. If your combined accessories use more electrical current than your charging system can produce, the consumption can discharge the battery leading to electric system damage. Ask your dealer for advice about the amount of current consumed by additional electrical accessories.

### Warranty Information

If this unit fails due to faulty parts, design or manufacturing for life of your purchase. We will replace or fix it. BUT All warranties will be voided IF the following guidelines are not followed:

- Do not cut any of the wires!
- Only use the battery harness, cigarette plug adapter, or BMW power port adapter. Attempting to use a home-made BMW or cigarette plug adapter will void the warranty.
- We are not responsible for units damaged by incorrect installation, use or shorts in the clothing.