

Multifit Panel Cigarette Socket Mount Installation

AKT-002



Introduction:

Made in USA

This easy to install, high quality kit provides a convenient way to access the battery on many motorcycles. The operator can supply power to many electrical devices (i.e. gps, cell phone, radar detector or music player).

Parts List:

- 1 - Wiring harness w/ 10A fuse
- 1 - Panel mount cigarette socket
- 1- Cigarette lighter element insert
- Ty-wrap(s)



Please read all of the instructions carefully before attempting the installation of this product. Please have a trained professional install this kit if you are unfamiliar with these procedures.

Quick Start Instruction:

- STEP #1 Remove panel & seat.
- STEP #2 Drill the panel and mount the socket.
- STEP #3 Route wires starting at the battery and finishing at the socket.
- STEP #4 Attach the wires to the socket and test.
- STEP #5 Look over your work.
- STEP #6 Put everything you took off back on.

Detailed Instruction:

STEP #1 – Remove the seat, exposing the battery.

STEP #2 – Locate a suitable place on the panel to drill and mount the socket. Use a flat spot on the panel. Drill a 1 1/8" hole through the panel using a hole saw. Do not use a flat wood drill. If the hole is too small for the socket open it with emery cloth or a file. Watch the clearance behind the panel. The required clearance behind the panel is approx 1 7/8". Use the supplied rubber washer between the socket and panel [A]. Attach the socket to the panel; use a dab of Silicone on the socket and jam nut.

Important: Do NOT ever use Loctite or over-tighten. Be careful with the use of the cigarette lighter element. Do not use lighter element when vehicle is in motion. Ejection of element may cause injury, vehicular damage or loss of control resulting in injury or death and should never be used while operating the vehicle under any circumstances. STEP #3 –

Stretch out the wiring harness. Grab the socket end of the harness and start routing the wiring harness; follow a stock wiring harness where possible. Poke the wires out of the hole where the panel was. Next remove the negative battery connection, followed by the positive battery connection. Slip the red wire under the red battery boot. You may need to trim the red boot to accommodate the added wire. Connect the red wire to the battery posts as follows:

RED WIRE = BATTERY POSITIVE

Tuck the fuse holder into any cavity near the plus terminal of the battery. Ty-wrap the fuse holder to the nearby wiring. Connect the black ground wire to any frame member such as the gas tank hinge bolt. If this is not possible attach the black wire to the negative battery terminal.



STEP #3 – Install the fuse in the fuse-holder. The center terminal is plus and the outer ring is negative. Connect the white connectors and Install the fuse. Use a voltmeter to check if the polarity is correct.

STEP #5 – Apply the remaining ty-wrap to the wiring harness and the existing wiring harness. Do NOT allow the harness to directly contact the motor or exhaust.



STEP #6 – Replace the panel and the seat.

Step #7 – To use cigarette lighter element, insert into socket and push down until it locks in place and wait approximately 20-30 seconds. Lighter element will eject from socket and can then be pulled out to light a cigarette. Be mindful that this element does get hot and you may burn yourself or your vehicle if not properly handled. Store once cooled beneath your seat or in a storage compartment. Not intended to be used with element plugged in at all times. Ride Safe and Enjoy!